



Office series Dual mode
version user's manual


In The Box:




Team Free x 1




Power Adapter X 1



HDMI Cable X 2




Wireless mouse X 1



Quick Start Guide X 1


Product structure :



Note: The device has no power switch. It will turn on when connected to a power source and shuts down after disconnection


Conference equipment connection :

① Power Connection




Eth connection

(Wired network connection is recommended for smoother video conferencing)



② HDMI-out to TV/Display





Note: The device should be deployed in an open area, keep the perimeter away from walls or obstructions. Otherwise, local reverberation will be formed, and the other party will hear echoes during the call.

Dual mode version – **First startup interface** Set resolution :

❶ First, you must switch the TV signal source to the connected HDMI

❷ Enter the boot interface to set the resolution. Please set it to 1920x1080.


Set resolution



Set to 1080P
resolution 60 frames

Note: Switching signal sources requires operation on the TV remote control. Some TVs can switch signal sources by voice operation. Please refer to the TV manual for settings


Dual mode version:




Note: Screen projection and HDMI cannot be turned on at the same time

Dual mode version – Start a zoom meeting:

① Enter the zoom meeting




② start a meeting



Note: Use the mouse buttons to operate, left button to enter and right button to exit.



Dual mode version – Start a skype meeting:

1 Enter the skype




2 start a meeting

Left click to enter



Right click to exit



Dual mode version – Screen sharing in meetings:

1 Share screen in meeting

Note: left click Return to main menu button



Switch camera
Front camera/HDMI camera



1: Share screen in meeting

2 Using TeamFree Open Capabilities



Camera sharing

HDMI video sharing

Mobile screen sharing



2: Use TeamFree Capabilities to share your screen

Note: During the meeting, you can press the back button to return to main menu and perform screen sharing operations. Click the meeting app to return to the current meeting.

Dual mode version – Screen sharing in meetings:

① Shared screen content seen on participants' phones

The shared screen using TeamFree capabilities seen by participants in the mobile-side zoom conference




② Shared screen content on participant PCs

The shared screen using TeamFree capabilities seen by participants in the PC-side zoom conference



Dual mode version – How to use TeamFree meetings:


main menu



TeamFree

Left click to enter
TeamFree meeting

Dual mode version – TeamFree meeting:



Tips: To delete a friend, long press the friend icon(5s) or long press the touch panel (5s) in WeChat and release.

Note: Screen projection and HDMI cannot be turned on at the same time





Add/Remove Friends :

1 add friends

camera scan friends
QR code to add

OR



WeChat applet/teamfree's App
added






friends QR code

2 remove friends

- Select the user icon and press and hold with the left button (5s)



-The WeChat applet/APP selects the user, long press the touch area (5s) and release






Del manage

Del friends


Note: The QR code of this device/friends can be viewed in the system settings page.

Function 1: Two-party conference


- 1 Select a friend, click to make a call /slide the touchpad of the control to select a friend, and double-click the touchpad to make a call.




- 2 The video stream can be turned on as needed when making a call. When the network is smooth, use camera + HDMI, or camera + miracast, when the network is poor, the camera can be turned off and use voice communication .



camera on/off



HDMI-in on/off



mobile projection
screen on/off

Note: Screen projection and HDMI cannot be turned on at the same time. After the Miracast is turned on, mobile phone (Android or Apple) can directly use the screen mirroring function.

Function 2: Three-party conference

① Three-way conference can call the common friends base on two-party call.

The screenshot shows a video conference interface with the following elements and annotations:

- Top Left:** TEAM FREE logo.
- Top Right:** Time 06-17 18:44 Fri, settings gear icon, and Wi-Fi icon. An annotation "call a second friend" points to the Wi-Fi icon.
- Left Side:** Three circular icons: a camera icon (labeled "camera on"), a speech bubble icon (labeled "HDMI-in on"), and a Wi-Fi icon.
- Main Area:** A large video window titled "Henrietta Shared" showing a presentation slide with the text "Scientific 科学可视化 01" and a 3D heart model. A smaller "Henrietta Video" window is overlaid on the bottom right of this window.
- Right Side:** A "邀请用户" (Invite User) panel with a plus sign and a user icon. Below it is a smaller video window titled "Lucinda HDM" showing a presentation slide with the text "Statistical 统计数据可视化" and "Geospatial 地理空间数据可视化". An annotation "Double click to maximize the video window" points to this window.
- Bottom Center:** A red scissors icon (labeled "hang up button"), a timer "12:33", and a text "one the phone...".
- Bottom Right:** A square icon with four arrows (labeled "Switch between local and friends video screen").

Tips: Click the small window in the dual video window to switch the size of the window. Double-click the large window to full screen the window. In a full-screen window, you can switch the video on the opposite end in the upper right corner.


Note: Screen projection and HDMI cannot be turned on at the same time

Preparation to use –APP remote control:


⑤ TeamFree's App remote control device

(TF Android app can be downloaded from the Google app store and TF Apple app can be downloaded from the Apple app store)



- 1) TF's App need to add box friends.
(TF is the abbreviation of TeamFree)



- 2) APP request management to box, the box agrees with the app management request





App friend operation interface




App remote control interface

⑥ The box side agrees with app management


After the box agrees with the app management, the app friend on the box will display the manager icon. When the manager is controlling the box, the icon color will change the color .



Manager icon




Manage remote controlling




Note: The first management request of the app, the box will pop up the consent dialog box, and after first management request will no longer pop up the consent dialog)

Preparation to use:

- ④ WeChat applet connection
(search for the Team Free remote control in the applet on the “Discovery” page of WeChat)
- Connect to the same wifi or the same local area network as the device, and scan the current local area network device.



Discovery device page



Modify username

return


Camera on/off

HDMI on/off

Mobile projection
on/off

Barrage font color

barrage switch



Control page

mic on/off

add friend

LED on/off

touch area

- Support sliding up, down, left and right to select
- Support double-click button and long-press action

Bullet screen
content input box

barrage send

Note: It must be in the same LAN/access to the same wifi as the connected device **Note: The barrage button is only available in live conferences**

Dual mode version – Switch to USB Device Mode :




Note: Switch to USB device mode requires restarting the device.

Dual mode version – Switch to USB Device Mode :


-- video conference: USB external camera, speaker and microphone

- 1 Click the settings icon on the main menu to enter the settings interface and turn on "USB conference device mode".



USB Conference device mode


- 2 Plug in the USB cable connected to the PC and restart the device. At this time, the external USB camera, microphone, speakers, etc. can be displayed on the PC. At the same time, the HDMI output is displayed as follows:



If your laptop has a Type-C interface, you can directly use a USB cable with type-C to connect the PC and TeamFree devices.

Dual mode version– USB mode device connection:



① Power Connection



Note: It is recommended that the USB cable be connected from the device to the computer first, and then powered on. The computer will have a high success rate in identifying the USB device and will not fail to recognize the device.

Dual-mode series - USB device displays after driver-free installation on a Windows:



① Right-click "My Computer" and select "Manage"



Note: If the device does not appear normally, you can power off and on again after connecting the USB. If it still cannot be recognized, please try changing the USB data cable.

Dual-mode series -- Testing camera:


- ② Search the "Camera" application in Windows applications to test the camera



Note: If the device does not appear normally, you can power off and on again after connecting the USB. If it still cannot be recognized, please try changing the USB data cable.

Dual-mode series -- Testing microphone and speakers:

③ Right-click the speaker and select Sound Settings to test the speaker and microphone.



Sound

Output

Choose your output device

Speakers (2- Source/Sink) ▾

Certain apps may be set up to use different sound devices than the one selected here. Customize app volumes and devices in advanced sound options.

[Device properties](#)

Master volume

100

[Troubleshoot](#)

[Manage sound devices](#)

Input

Microphone (High Definition Audio Device)

Capture Input terminal (2- Source/Sink)

Certain apps may be set up to use different sound devices than the one selected here. Customize app volumes and devices in advanced sound options.

[Device properties](#)

Test your microphone

[Troubleshoot](#)

[Manage sound devices](#)

Play music to test the speakers

Test microphone

Dual mode series - Select camera, microphone and speaker in Zoom conference:

1 Right-click the speaker and select Open Sound Settings to test the speaker and microphone.

The image shows two screenshots of the Zoom settings interface. The left screenshot shows the 'Video' settings page with the 'Camera' dropdown menu highlighted in red, showing 'UVC Camera' selected. Below it, the text 'Select device camera' is written. The right screenshot shows the 'Audio' settings page with the 'Speaker' dropdown menu highlighted in red, showing 'Speakers (2- Source/Sink)' selected, and the 'Automatically adjust microphone volume' checkbox highlighted in red. Below the right screenshot, the text 'The device's own audio processing does not need to be turned on' is written with an arrow pointing to the checkbox.

Video Settings:

- General
- Video**
- Audio
- Share Screen
- Team Chat
- Zoom Apps
- Background & Effects
- Recording
- Profile
- Statistics
- Keyboard Shortcuts
- Accessibility

Camera: UVC Camera

My Video:

- Original ratio
- HD
- Mirror my video
- Touch up my appearance
- Adjust for low light

Audio Settings:

- General
- Video
- Audio**
- Share Screen
- Team Chat
- Zoom Apps
- Background & Effects
- Recording
- Profile
- Statistics
- Keyboard Shortcuts
- Accessibility

Speaker: Speakers (2- Source/Sink)

Microphone: Capture Input terminal (2- Source/Sink)

Automatically adjust microphone volume

Audio Profile:

- Zoom background noise removal (recommended for most users) ?
- Personalized audio isolation (recommended for headsets with microphone) ?

Background noise suppression:


- Auto (automatically adjusts noise suppression)
- Low (faint background noises)
- Medium (computer fan, pen taps)
- High (background speech)

Dual mode series - WeChat applet remote control device:

- 1 WeChat applet connection (Search for Team Free remote control in WeChat's "Discover" page applet)
- 2 Connect to the same wifi or the same LAN as the device and scan the current LAN device.



Discover USB device interface




Note: Turning HDMI on and off when it is not connected to the device will cause the device to freeze, please wait patiently.

Modify device name

Camera on/off

HDMI on/off

Screencast on/off



Remote control interface

Device name

Configure wifi connection for device

Note: Configuration errors will cause the device to be unable to connect to wifi

Switching position between large and small windows

Dual stream setting small window position


- Support upper left, lower left, upper right, lower right

Note: It must be on the same LAN/access to the same wifi as the connected device. After setting up the device wifi, you need to reconnect the phone to the set wifi.



Dual-mode series -- Mobile App remote control :

❶ Mobile APP remote control device (download teamfree from google App market)



- 1) The mobile APP needs to be in the same LAN or wifi as the device



App find menu



Scan USB devices



USB device control



Note:

Please check the wifi name and password connection. If the config is incorrect, the remote control will be unusable and you need to switch to the host mode for wifi settings.

Note: The network where the mobile APP is located needs to be in the same LAN as the device or connected to the same wifi.

Dual-mode series -- USB mode Switch to Host mode


- 1 press Mic disable button to switch



To switch to Host mode, you need to use an HDMI cable from the HDMI-out interface to connect to a TV or monitor.

- 2 Power off and on again and restart the device.

switch memu




Note: Press the mute button switching to setting mode requires connecting HDMI-out to a TV or monitor




TEAM FREE APP
quick start

App add friends


Scan QR code add friends/enter live broadcast



Scan QR code add friends





QR code box



Select QR code in the album

QR code scanning frame




Scan friends QR code

Note: Friends have two types 1.teamfree device. 2 mobile apps.


Mobile friend communication function

Mobile phone friend




Mobile friend type


Delete friend




Poke poke, safety chat,
video



Poke poke function



Safety chat function




video call function

Note: When the poke function is mainly used for the opponent's app is not online, push notification message to the side mobile phone prompt to request the other party to go online .


Note: The safety chat function can only be used for both parties online.

TeamFree Device friends communication function

Device friend



Mobile friend type



Video conference, watch live conference, manage equipment




In the live conference

Barrage operation

Request call

Call third-party users



Open/off friends video

Open/off the local video

Switch camera

Switch to horizontal screen

Video call

Video conference -horizontal screen mode :

Friend name

Open/off video

Click to switch the size window

Small windows can be dragged

Hang up call

Call third -party friend

Horizontal/vertical screen switch


wl0103

local


Meeting 16:45

Note: After calling for third -party friends, a three -party video conference will be formed .


Manage the Teamfree device function



Device business interface




Management control interface




Equipment communication backup restore interface



Gadget – freeze photo :



freeze photo




fixed shooting





fixing

Note: freeze photo is used with the mobile phone screen function with the Teamfree device. After the fixed shoot. The camera will keep the image in the fixed freeze, you can observe the shooting details

Gadget – USB Device Control:




USB device control



Scan USB devices

Modify device name


Camera on/off



HDMI on/off

Note: Turning HDMI on and off when it is not connected to the device will cause the device to freeze, please wait patiently.

Screencast on/off



Device name

Send wifi configuration to device

Switch size window position

Set the position of the small window

- Support upper left, lower left, upper right, lower right

USB device control

Note: The network where the mobile APP is located needs to be in the same LAN as the device or connected to the same wifi.

Shenzhen JIANCHENG YUNSHI Technology Co., Ltd.

Address: Room 1701, Building 4, Bangyan Green Valley Factory, No. 98 Zhihe Road,
Dakang Community, Yuanshan Street, Longgang District, Shenzhen City

Email: service@giantsee.com

Website: www.team-free.com